



08-13 Cadillac CTS Diffuser Fins



Installation Quick FAQs

1/8" drill bit needed for installation. Screws included in the package. Larger fins are for the center section of the bottom rear bumper, shorter fins are for the outer sections of the rear bumper. Example of installation shown below

